



## Reusable Pallet Shipper for a More Sustainable Future

We've taken our globally recognized Silverpod MAX passive pallet shipper and enhanced it for reuse to bring you CSafe's Silverpod MAX RE—a highly durable PCM pallet shipper made entirely of reusable components.

An alternative to our single-use pallet shippers, this new product is a sustainable solution with the reliability and exceptional quality that CSafe is known for. It includes a built-in TracSafe RLT data logger that integrates with CSafe Connect for real-time shipment visibility throughout the entire journey.

We have also made key enhancements, like adding durable exterior panels and extended edge and corner cap protection, to create a premium reusable model to help you achieve your sustainability goals. Further, our rental structure allows you to eliminate disposal costs, bringing added value to your business and your customers—with minimal impact on the environment.



### Key Features



Reusable components and recyclable Pharmacool™ MAX PCM coolants



Turnkey refurbishment services included and provided by CSafe



120+ hours of qualified thermal protection



Easy conditioning process with PCM coolants, providing enhanced thermal protection and safe storage—both before and during shipping



Integrated TracSafe RLT data logger provides real-time access to tracking and conditional data through our cloud-based CSafe Connect platform



Quicker, more efficient assembly with our universal packing process



Supplies flat packed for cost-effective delivery and storage




Available worldwide




## Benefits of Our Reusable Technology



Reduces environmental impact



Decreases energy consumption



Minimizes waste



Strengthens your operational efficiency

## Technical Specifications

PRODUCT NAME	PAYLOAD VOLUME	TEMPERATURE RANGE	DURATION	PAYLOAD DIMENSIONS L x W x H	EXTERNAL DIMENSIONS L x W x H	TARE WEIGHT (W/O PCM)	TARE WEIGHT (W/ PCM)
Silverpod MAX RE Single	1442 L 50.9 cu ft	+2°C to +8°C	120+ hrs	1244 x 1054 x 1100 mm	1575 x 1386 x 1570 mm	115 kg	268 kg
Silverpod MAX RE Quarter	1182 L 41.7 cu ft	+2°C to +8°C	120+ hrs	1220 x 850 x 1140 mm	1575 x 1208 x 1580 mm	105 kg	266kg

Contact us at [passivesolutions@csafeglobal.com](mailto:passivesolutions@csafeglobal.com)

CSafe has a global network of service centers, stations, supply points, and team members to provide support and solutions where and when you need them. CSafe and the logo designs presented in this material are trademarks or registered trademarks of CSafe. ©2024 CSafe